

NA - OM5II

For Olympus OM-5II Camera

PN 17822

User Manual

Housing

MIL

Introduction	2
Package Contents	2
Important Instructions	3
Part Names and Functions	4
Housing Mount	7
Opening the Housing	8
Closing the Housing	9
Preparation for Use	10
Optional Accessories	16
Care/Storage	18
Warranty	19
Specifications	20


INTRODUCTION

Thank you for purchasing this Nauticam product.

Before using the product, please read this manual thoroughly to familiarize yourself with full scope of functions on the product as well as ensuring that you will use the product correctly.


PACKAGE CONTENTS

Make sure that you have all the included items listed below before using this product.
If some items are missing or damaged, contact your local Nauticam dealer.




NA-OM5II


(2 x Plugs for Optical Fiber Cable Mount,
1 x Housing Cap.)




Padded Travel Case



Allen key set




Lubricant




Panasonic CR2032 Battery

(pre-installed for Moisture Alarm)



Spare Main O-ring
#90139

After purchase, we suggest that
you reuse all packaging materials
for future travelling.



O-ring Remover

IMPORTANT INSTRUCTIONS

1

Water-tight test of the housing (without camera inside) before usage is recommended as well as any O-ring renewal and port change.

2

Do not seal the housing when travelling by air as this may lead to a pressure difference between the atmosphere and inside the housing.

3

Only the accessories specified by Nauticam must be used. Third-party accessories may result in malfunctions or damage to the product.

4

Use only Nauticam lubricant on silicone rubber O-ring.

5

Do not stretch any O-rings excessively. Only remove it using Nauticam O-ring remover.



6

Discontinue use immediately when there is a sign of leakage.

7

Do not attempt to remove parts of the housing yourself. Repairs must be done at authorized service centers only.

8

The housing should be positioned on the a stable and safe surface on land.

9

Do not expose the housing in direct sunlight for a prolonged period.

10

Do not open the housing in wet or sandy environment. Protect the housing from moisture and debris in order to prevent malfunction or leakage.

11

Prevent any sand or dust or water penetration inside the housing. Be extra careful when changing lens and inserting or removing the camera.




12

This product is not intended for use by children, or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they are supervised and/or given instruction by a responsible person concerning use of the product to ensure that they can use it safely.

PART NAMES AND FUNCTIONS

Rear View



1 Moisture alarm window

3 REC button

5 AF-ON button

7 INFO button

9 Down button

11 Delete button

13 Up button

A Quick control/set button

2 FN lever

4 Thumb position

6 ISO button

8 Right button


10 Playback button

12 Left button

14 Menu button

PART NAMES AND FUNCTIONS


Top + Front Views



- | | |
|---|------------------------|
| 1 M16 Accessory port | 2 ON/OFF lever |
| 3 Sequential/self-timer shooting button | 4 LV button |
| 5 M14 Accessory port | 6 Front dial |
| 7 M10 Accessory port | 8 CP button |
| 9 M-LOCK button | 10 Rear dial |
| 11 Mode dial | 12 Port index mark |
| 13 Optical fiber cable connection | 14 Lens release button |

PART NAMES AND FUNCTIONS

Bottom + Side Views



1 1/4" Threaded tripod holes

3 Zoom/Focus knob


5 Port locking lever

2 Sacrificial zinc anodes

4 Port lock safety button

6 Housing unlock button

HOUSING MOUNT



Housing mount


Compatible accessories

1	M10 Accessory port	25221	M10 Strobe Mounting Ball for Housing
2	M14 Accessory port	25624	M14 Vacuum Valve II (pushbutton release)
3	Cold shoe	25311	Strobe Mounting Ball for Cold Shoe
		25312	Light Mounting Stem for Cold Shoe
		25321	Long Strobe Mounting Ball for Cold Shoe
		25322	Long Light Mounting Stem for Cold Shoe
4	M16 Accessory port	25028	Socket Extension for 25032 HDMI Bulkhead with M16 Thread
		25032	Custom HDMI Bulkhead to use with Socket Extension
		25076	HDMI (D-D) Cable in 200mm Length
		25047	HDMI (D-D) Cable in 800mm Length
		25082	HDMI 1.4 Cable for Ninja-V Housing
5	Hand straps	36316	Hand Strap for Mirrorless IL Camera & Compact Camera Housing
		36323	Long Hand Strap for Mirrorless IL Camera & Compact Camera Housing
6	1/4" -20 Mounting threads	71208	Adjustable Right Handle II
		71209	Flexitray Plate II with Left Handle

OPENING THE HOUSING


* drawings as illustrations only

1




depress housing unlock button

2



turn housing lock latch
anti-clockwise to open the
housing

3




flip open the back housing
when lock latch is aligned to
'open' position

CLOSING THE HOUSING

* drawings as illustrations only


1



before closing the housing, clean and lubricate the main O-ring


make sure nothing is caught between front and back housing and that they are fully aligned before locking

2



insert the housing shaft into the shaft hole and then rotate the lock latch clockwise until you hear and feel it click into place


3



housing locked in place securely

PREPARATION FOR USE

The below settings for Eye Sensor Setting must be adjusted before installing the camera inside the housing :




In the Custom Settings menu, under **Eye Sensor Settings/EVF Auto Switch (Release button to use dial)**, Select **[OFF]**. Only by using the LV button can you switch between LCD/VF display; otherwise, it will stay in VF mode after closing the back housing.

PREPARATION FOR USE

* drawings as illustrations only


Installing the Camera - housing tray attachment

1



unlock camera tray lever and remove the tray from the housing


2



attach the camera tray by tightening the tray screw into the tripod socket of the camera

place the actuator on the camera tray in place and make sure it is engaged with the camera


3



** lift up ON/OFF lever each time before installing the camera then turn the ON/OFF lever to ON position*
** pull out the zoom/focus knob if installing the camera with lens and gear attached*

slide the camera tray back into the housing along the tray rail

4



lock camera tray


** place the zoom/focus knob in place and make sure it is engaged with lens gear*

PREPARATION FOR USE

* drawings as illustrations only


Port Mounting

1



depress safety button and rotate anti-clockwise

2




lubricant the port O-ring before mounting

align index mark

push port assembly straight in

3




rotate locking lever clockwise to lock

 *Do not operate the red lever with force, make sure the port is aligned correctly and pushed in fully and securely*

PREPARATION FOR USE

* drawings as illustrations only

Coating housing O-ring



1
remove the main O-ring using an O-ring remover

2
clean the O-ring groove with a cloth and ensure
that it is free from salt or other foreign materials


3
lightly coat it with provided lubricant

4
return the main O-ring by slowly pressing from
one corner to the whole perimeter


PREPARATION FOR USE

* drawings as illustrations only

Setting up moisture alarm




1




remove battery
insulation film

2




press the battery down until it
click into place

3



switch on the alarm
- the moisture alarm
window will flash in
BLUE when it is working
correctly

4



test the alarm
- connect the wires with a
dampened cotton bud; the
alarm will give a repeating
'beep' and the moisture alarm
window will flash **RED**


* please contact our authorized service centers if testing fails
* please refer to page 16 for complete vacuum system guidance

PREPARATION FOR USE

* drawings as illustrations only

Changing lens/port without opening the housing

1




If using with vacuum valve :

remove the cap from the vacuum valve and press the red button to release pressure before unlocking port lock


If using without vacuum valve, please follow from step 2

2




unlock port lock and remove port assembly

3



press the blue button to reset vacuum alarm before replacing port

4




replace port assembly then lock port lock

reset vacuum valve system using hand pump and close the cap after

* please refer to page 16 on complete vacuum system guidance


OPTIONAL ACCESSORIES

1



- remove the plug of M14 accessory port from the housing
- remove the cap from the vacuum valve
- slightly lubricate the o-ring and make sure the o-ring is in place
- then tighten the vacuum valve to the housing with the tool provided

2



- connect hand pump to the valve and pump several times until it reaches the target vacuum level
- close vacuum valve cap

Moisture alarm window colour indication :

Steady Blue		device is turned on
Flashing Blue		standby mode, ready for pumpng
Steady Green		target vacuum level is reached
Flashing Yellow		vacuum level is dropping
Flashing Red		vacuum is totally lost, circuit stalled untill device is switched off
Alternating Blue and Red		vacuum is totally lost, circuit stalled untill device is switched off
Steady Red		out of battery

** It is recommended to leave the housing for at least 20mins to ensure it is sealed. If the LED light changes from steady green light to rapidly flashing yellow light, that means there is a leakage. Please check every O-ring and then conduct the vacuum test again.*


** please contact our authorized service centers if testing fails*

OPTIONAL ACCESSORIES

* drawings as illustrations only


Installing Surface USB-PD Power Bank

1




unscrew the M16 accessory port cap from the camera housing

2



plug the USB-C Bulkhead into the accessory port, gently push the connection head into the accessory port until it cannot go further then tighten it by turning the locking nut


3



plug the cable into the USB Type-C jack on the camera with camera tray attached before sliding into the camera housing

slide the camera tray into the housing along the tray rail then lock camera tray

4



close the housing gently

plug the power bank with USB Type-C connector into the USB-C bulkhead

CARE/STORAGE

1

Soak the housing system in fresh water after salt water usage

2

Operate all controls and buttons at least 3 times while immersed in fresh water

3

We recommend cleaning and inspecting the main O-ring each time after diving for any damage and every time the housing is opened.

4

Protect the housing with robust and shock-proof travel case during transportation. Do not travel with camera inside housing.

5

We recommend to ship the housing to our service centers for a complete overhaul after 500 dives/every 3 years.

WARRANTY

All NAUTICAM Housing Products and Viewfinders are warranted against any material and manufacturing defects for two years from the date of purchase for consumer use. NAUTICAM Optical Accessories are warranted against material and manufacturing defects for a period of one year, and HDMI cables carry a year warranty.

This warranty only applies to products purchased from authorized NAUTICAM dealers and does not extend beyond the original retail purchaser.

To return your product for service, please contact your regional authorized service center(s). Please note that this warranty only applies when the product is purchased in the territory where the service center is located.

NAUTICAM accepts no liability for any damage to and defects in the housing caused by improper use and/or poor maintenance; it is the responsibility of the owner to carefully follow the instructions in our manuals.

NAUTICAM does not hold responsibility for damage, of any nature, to any equipment used with and/or placed within our products.

NAUTICAM accepts no liability for any loss of captured images or the inability to capture images even if it is due to the malfunctioning of our products.

Unauthorized modifications and/or repairs of our products will automatically invalidate the warranty.

SPECIFICATIONS

Construction

Housing body	Hard Anodized Aluminium Alloy
Display window	Abrasion Resistant Polycarbonate

Dimensions

Width	197 mm
Height	154 mm
Depth	99 mm

Weight

In air	1.30 kg
Buoyancy in water	- 0.014kg (incl. camera and battery)

Depth

Rating	100 m
--------	-------

Port Specifications

Port mount	N85 Micro Four Thirds Port System
Port accessories	1 x M10, 1 x M14, 1 x M16

Viewfinder

32222 NA-OM5II LCD Window for Nauticam Full Frame Viewfinder
32215 Viewfinder Collar Adaptor for 32211/2/3/4 to use with MIL Housings
32211 Nauticam Full Frame Straight Viewfinder 32°/ 1:1
32213 Nauticam Full Frame Angle Viewfinder 32°/ 1:1

** A new LCD window and 32215 are required to use with 32211/32213*

Buoyancy Options

72216 Ø70x200mm Carbon Fibre Aluminium Float Arm (Buoyancy 370g)
72217 Ø70x250mm Carbon Fibre Aluminium Float Arm (Buoyancy 520g)
72218 Ø70x300mm Carbon Fibre Aluminium Float Arm (Buoyancy 670g)
72219 Ø90x170mm Carbon Fibre Aluminium Float Arm (Buoyancy 450g)
72220 Ø90x220mm Carbon Fibre Aluminium Float Arm (Buoyancy 720g)
72233 Single Bayonet Holder II for Ø70 Float Arm
72234 Double Bayonet Holder II for Ø70 Float Arm
72243 Single Bayonet Holder II for Ø90 Float Arm
72244 Double Bayonet Holder II for Ø90 Float Arm
83252 Bayonet Holder for Arms
83253 Double Bayonet Holder for Arms
83254 Bayonet Lens Holder for Inon Float Arms
87516 EMWL Bayonet Holder for Ø70 Float Arm
87517 EMWL Bayonet Holder for Ø90 Float Arm

Recommended Accessories

71311 Strobe mounting ball for Easitray & Flexitray
71208 Adjustable Right Handle II (for Easitray II & Flexitray II)
71209 Flexitray Plate II W with Left Handle (with 2 tripod holes)
25200 Compact/MIL Housing Shutter Release Extension
36316 Hand Strap for Mirrorless IL Camera & Compact Camera Housing (Standard)
36323 Long Hand Strap for Mirrorless IL Camera & Compact Camera Housing

FLASH TRIGGERING

Optical

Manual Flash Trigger

26306 Mini Flash Trigger for Olympus
<i>* NA-OM5II Housing is only compatible with #26306 from SN A625591 onwards</i>

WET LENS COMPATIBILITY

** please refer to Nauticam port charts for more setup information*

Nauticam optical lenses

Macro	81203 Super Macro Converter 3 (2.3x Magnification)
	81301 Compact Macro Converter 1 (CMC-1, 4.5x Magnification)
	81302 Compact Macro Converter 2 (CMC-2, 2.8X Magnification)
	81501 Mid-range Focus Optimizer 1
	81503 Mid-range Focus Optimizer 3
Macro to Wideangle	87301 EMWL Set #1 (incl. focusing unit #1, 150mm relay lens and 3 objective lenses)
	87201 EMWL Focusing Unit #1
	87211 EMWL 150mm Relay Lens
	87212 EMWL Angled Relay Lens
	87221 EMWL 60° Objective Lens
	87222 EMWL 100° Objective Lens
	87223 EMWL 130° Objective Lens
	87226 EMWL 160° Objective Lens
Wideangle	83202 Wet Wide Lens 1B (WWL-1B) 130 deg. FOV with Compatible 28mm Lenses (incl. float collar)
	83203 Wet Wide Lens Compact (WWL-C) 130 Deg. FOV with Compatible 24mm Lenses (incl. float collar)
	86201 Macro to Wideangle Lens 1 (MWL-1) 150 deg. FOV with full frame 60mm macro lens

Optional accessories

25101 M67 flip diopter holder for M67 macro ports
25108 M67 Double Flip Holder for M67 Macro Ports
83250 M67 to Bayonet Converter II
83251 M77 to Bayonet Converter II
83214 Bayonet Mount Adaptor for SMC/CMC
87501 Flip Holder for EMWL
87512 Shade for 130° Objective Lens
87513 Shade for 100° Objective Lens
87518 Strobe Mounting Brackets for EMWL Relay Lens
87519 Shade for 160° Objective Lens

HDMI CONNECTION & MONITOR OPTIONS

HDMI Connectivity Required Accessories (1.4)

25028 Socket Extension for 25032 HDMI Bulkhead with M16 Thread
25032 Custom HDMI Bulkhead to use with Socket Extension
25076 HDMI (D-D) Cable in 200mm Length
25047 HDMI (D-D) Cable in 800mm Length
25082 HDMI 1.4 Cable for Ninja V Housing in 0.75m Length

** 25047 is required for use with 16612 monitor housing*

** 25082 is required for use with 17922 monitor housing*

Monitor Options (1.4)

16612 Nauticam 7" T7 UW ULTRAHD Monitor
17927 NA-Shinobi II Housing
17922 Nauticam Atomos Ninja V Housing

Nauticam Internationl Ltd.

Rm 2203, CCT Telecom Bldg,
11 Wo Shing St,
Fo Tan,
Hong Kong

Tel. +852 - 26902711
Fax. +852 - 26909778
URL. www.nauticam.com
Gallery. www.nauticam.smugmug.com